

Service Manual H-5200

Telescoping Arm System with Vacuum Package

Rev 5 - 1-14-20 900-089M

- Installation 1. Place the shipping carton in the desired location. Remove the vacuum system with telescoping arm from the shipping carton.
 - 2. Mount the post clamp to the post at the desired height.
 - 3. Insert the rigid arm into the post clamp.
 - 4. Place the HVE and S/E valves in their holders and connect the tubing to the ports on the vacuum cannister. Connect the drain and syringe tubing to the appropriate connections.
 - 6. Place the syringe in its holder.

Final <u>Adjustments</u>

Check air pressure, adjust to 80 psi if necessary.

Check water pressure, adjust to 40 psi if necessary.

Check vacuum cannister for solids screen.

Test HVE and S/E valves for proper function.

Test syringe for proper pressure and function.

- Operation 1. Insure that the central vacuum system is turned on and air and water pressure are at the proper setting.
 - 2. Lift the vacuum valve out of the holder and push the lever down towards the base of the valve to allow vacuum to begin.


- **Cleaning** 1. Separate valve from tubing at the quick disconnect swivel by pulling them apart. Remove the lever and the spool and clean in an ultrasonic cleaner.
 - 2. Rinse thoroughly before putting components into autoclave.
 - 3. Lubricate O-Rings on the spool only with a silicone based lubricant and reassemble.

Autoclavable HVE & S/E Valves

Maintenance Autoclavable vacuum valves may be autoclaved by steam autoclave or a chemical vapor. Due to the tight clearances and hardness of the anodized surfaces, the valve spool can become jammed or seize in the valve if it is sterilized while contaminated with debris.

Valves can be quickly disassembled for cleaning.

- 1. Pry one side of the lever and flip it off of the valve. For saliva ejector valves, remove the tip also.
- 2. Push out the valve spool and clean all the disassembled parts in an ultrasonic cleaner daily. Rinse thoroughly before putting into autoclave.
- 3. Lubricate the O-Rings on the spool with a silicone based lubricant before reassembly.



| 1 | Tip112-174 | 1 |
|---|---------------------|---|
| 2 | Body112-276 | 1 |
| 3 | Spool112-278 | 1 |
| 4 | O-Ring #10017-110 | 2 |
| 5 | O-Ring, #12 017-012 | 1 |
| 6 | Swivel 112-177 | 1 |
| 7 | Lever112-181 | 1 |

AUTOCLAVABLE S/E LEVER VALVE, CHROME

AUTOCLAVABLE UNIVERSAL HVE VALVE 112-263

PART NUMBER QTY

.....017-113 3

....112-272 1

...112-268

.....017-013 1

..... 112-170 1 ..112-169 1

ITEM PART DESCRIPTION


3 Spool, Chrome......

Swivel.....


2 Body, Chrome.....

1 O-Ring, #13.....

4 O-Ring, #13......



| ITEM PART DESCI | RIPTION PART NUMBE | ER QTY | ITEM | PART DESCRIPTION | PART NUMBER | QTY |
|-----------------|--------------------------|------------------|------|------------------------------|---------------|-----|
| 1 Screw, 10-3 | 2 x 1/4" 001-03 | 32 1 | 17 | Telescoping Arm Slide | 105-214 | 1 |
| 2 Screw, 10-3 | 2 x 3/8"001-07 | ⁷ 0 1 | 18 | Telescoping Arm Tube | 105-216 | 3 |
| 3 Screw, 6-32 | x 1/4" 001-13 | 33 1 | 19 | Telescoping Arm End Cap | 105-217 | 6 |
| 4 Screw, 8-32 | x .25001-14 | 19 2 | 20 | 105-218 With Modified Tab | 105-218 | 6 |
| 5 Screw, 8-32 | x .375001-16 | 51 7 | 21 | Telescoping Arm Front Slide | Guide 105-219 | 2 |
| 6 Carriage Bo | lt 1/4-20 x 1-3/4"001-44 | 16 1 | 22 | Telescoping Arm Slider Block | 105-220 | 1 |
| 7 Lock Nut 3/ | 8-24002-00 |)2 1 | 23 | 7" Holder Bar Assembly | 105-223 | 1 |
| 8 Washer 1/2 | <u></u> 003-00 |)6 1 | 24 | Vacuum Cover | 105-230 | 1 |
| 9 Washer Sho | ulder S-5325003-01 | 13 10ft | . 25 | Vacuum Chassi | 105-232 | 1 |
| 10 Washer 3/8 | ' 003-02 | 25 1 | 26 | Telescoping Arm Pivot | 105-258 | 2 |
| 11 Screw, 6-32 | x 3/8"005-01 | 18 1 | 27 | Universal HVE Valve | 112-263 | 1 |
| 12 Mechanical | Flex Housing pin009-01 | 13 1 | 28 | Autoclavable S/E Valve | 112-280 | 1 |
| 13 HVE Port Ca | p010-00 |)9 1 | 29 | Syringe Adustment Block | 113-026 | 1 |
| 14 8" Folding / | Arm Section 105-03 | 39 1 | 30 | Syringe | 113-400 | 1 |
| 15 2″ Post Moເ | nt Clamp 105-05 | 51 2 | 31 | Syringe Holder | 141-200 | 3 |
| 16 Telescoping | Arm Slide Housing 105-21 | 12 1 | 32 | Vacuum Canister | 131-036 | 1 |
| | - | | | | | |



9

(10)

11

12

- 2. Remove the syringe tip adapter using the hex wrench.
- 3. Insert the new syringe tip adapter into the syringe head and tighten using the hex wrench.
- 4. Place the two (2) O-Rings into the syringe tip nut.
- 5. Screw the syringe tip nut onto the syringe tip adapter and tighten using the hex wrench.
- 6. Push the syringe tip into the syringe tip nut until it snaps into place.

Replace Syringe Tip

1. Pull the dirty syringe tip out and insert a clean syringe tip into the syringe tip nut until it snaps into place.

| 1 Syringe Tip | Υ |
|--------------------------------------|---|
| | |
| 0 0 0 0 000 | |
| 3 O-Ring, 006017-006 2 | |
| 4 O-Ring, 228-040017-023 1 | |
| 5 Syringe Tip Adapter113-227 1 | |
| 6 O-Ring, 003017-003 1 | |
| 7 Syringe Head113-405 1 | |
| 8 Syringe Button Repair Kit113-403 2 | |
| 9 Pin, Syringe Cartridge113-008 1 | |
| 10 Plastic Washer, 8-32003-030 2 | |
| 11 Barb, 8-32 x 1/16"022-040 2 | |
| 12 Syringe Handle113-236 1 | |

WARRANTY BDS warranties its product to be free of defects in material and workmanship for SEVEN FULL YEARS from the date of purchase on all units. Auto-blocks and standard foot controls are covered by a LIFETIME warranty when factory installed as part of a complete dental system. Upholstery has a TWO YEAR warrany and does not cover normal wear, stains, cuts or tears. Our LED lights have a FIVE year Warranty and our halogen light has a ONE year Warranty. Operatory chair motors feature a TEN year warranty. All warranty is limited to repair or replacement by BDS. Products returned to the factory and determined to be defective will be repaired or replaced free of charge at discretion of BDS. The warranty does not cover light bulbs, electrical components and trimmed or installed tubing. BDS reserves the right to void all warranties if any product is installed by other than an authorized technician. BDS' warranty does not cover damage to any surface finish, including but not limited to, discoloration or abrasion from cleaners, disinfectants or light sources. No claim for labor or consequential damages will be allowed. Return items must include a copy of the invoice or packing slip as proof of purchase.

Beaverstate Dental Inc. 115 S. Elliott Rd. Newberg, OR 97132 800-237-2303 503-538-8756 503-538-2845 Fax www.beaverstatedental.com